

INSTALLING TRASH CAN INSERTS

AC-WBS15 goes in a B15 cabinet

AC-WBD18 goes in a B18 cabinet

These instructions are for installing insert before countertops are on cabinets.

1. Screw brackets to sides of wooden frame into predrilled holes.
2. Remove door and hinges from cabinet.
3. Place insert inside cabinet aligned with edge of face frame.
4. Carefully align door so that it is even with adjacent cabinet doors.
5. Mark through the screw holes onto back of cabinet door.
6. Predrill holes in back of cabinet door, being careful not to go through the front of the door.
7. Screw door to brackets using the short screws.
BE CAREFUL NOT TO SCREW THROUGH FRONT OF DOOR.
8. Position insert inside cabinet so that door closes completely.
9. Mark screw holes in bottom of cabinet, predrill and screw to cabinet using the longer screws.
10. Alternatively you can use the slots in the frame to screw insert to bottom of cabinet.
Position as desired and then tighten screws.



BAG INCLUDES EXTRA SCREWS